

AGPTEK

Portable Door Lock

Installation Instructions



Installation steps as seen in the above pictures:

- Step 1&2:** Before installing the portable lock, test to see if it will fit. Insert the back of the nickel-plated handle (part ③) between your door and the frame where the lock is (see image 2). If it fits smoothly, then you have the space to insert the portable lock. (Proceed to step 3)
Note: Do not force the door shut if there is no room.
- Step 3:** Open the door towards you and insert the claws of the portable lock (part ①) into the strike of the door.
- Step 4:** The red handle (part ④) with moving metal rod (part ⑤) is what locks the door in place.
- Step 5:** Once the claws of the portable lock (part ①) are inserted into the strike of the door frame, close the door. The nickel-plated body is now locked in place.
- Step 6:** Take the red handle (part ④) by holding the top of it (widest part in image 4) and insert the moving metal rod (part ⑤) into the triangular hole (part ②) of the nickel-plated body of the lock (see image 6) . And please note that the triangular hole inserted should be on the side between the nickel plated body and the door handle. The red handle will slide down till it locks the door in place.
Note: Once you have completed the above steps, the handle of portable lock should be wedged against the door (see image 7). Your portable lock is now in place.
- Remove:** To remove the portable lock, lift the red handle and remove the moving metal rod from the triangular hole. The door can now be opened and release the nickel-plated body from the strike plate. Keep the portable lock handy so you can reuse it. Hanging it by the door on a hook makes it easy to find when you need to use it the next time.
- Uses:** Fits most doors that are hinged and swing inwards. Use for additional safety and privacy. The front door, other doors in your home, cottages, hotels, motels, hostels, apartments, university dorms, rented rooms, or any shared accommodation. Keep it in your travel bag.

AGPTEK

内開き扉専用補助錠

工事不要で簡単にロックを追加



上記の写真の手順通りにインストールを行います：

- 補助錠を取り付ける前に、まずドアを開けて図 2 のように補助錠プレートの③の部分ドアとドア枠の間に差し込んでみてください。スムーズに差し込める場合なら、補助錠を利用できるスペースがあることを示します。
注：無理に差し込めないでください。
- 図 3 のようにドアを手前に開き、補助錠プレートの①の部分をドア枠の金具に引っ掛けます。
- 図 5 のようにドアを閉めて補助錠のプレートを挟み込みます。
- 赤いハンドル（④の部分）の上部を持ち、丸い金属物（⑤の部分）を三角形の穴（②の部分）に挿入します。ご注意：赤いハンドルは、補助錠のプレートとドアハンドルの間にあります（図6を参照）。赤いハンドルがしっかりと固定するまで、丸い金属物を穴の中にスライドします。
注：上記の手順を完了したら、ドアを開けられるかどうかをご確認ください。開けない場合、完璧に設置完了となります。

取り外しの方法について

補助錠を取り外すには、赤いハンドルを持ち上げ、丸い金属物を三角形の穴から取り外します。ドアを開けて、プレートをドア枠の金具から外します。赤いハンドルをドアのフックに掛けると、次に利用するときに簡単に見つけることができます。

用途

ほとんどの内開き扉に適用します。追加鍵として、セフティやプライバシーを守るために使用されます。適用シーン：鍵のないドア、一人暮らし部屋、旅行、ホテル、アパート、学生寮、賃貸部屋、または共有の宿泊施設、もう一つロックがあればより安心しますね。